



## AQUAGUARD 5000 1 GALLON VINYL LINER STAIRS INSTRUCTIONS

### 2:1 MIX RATIO

1. Sand Stairs with an orbital sander with 60 grit paper
2. Wipe Stairs thoroughly with MEK or Acetone Solvent
3. Tape all areas not to be painted.
4. To Mix the following quantities:

- a. 1 Gallon – 84 oz. Part A Resin  
42 oz. Part B Hardener  
12 oz. Epoxy Reducer (Xylene)
- b. ½ Gallon – 42 oz. Part A Resin  
21 oz. Part B Hardener  
6 oz. Epoxy Reducer (Xylene)
- c. 1 Quart – 21 oz. Part A Resin  
10.5 oz. Part B Hardener  
3 oz. Epoxy Reducer (Xylene)

Always mix counter clockwise to avoid spillage & air entrapment.